

MAINTENANCE MENU

Toyota requires two primary services plus some additional items at specific intervals. For spark plug, automatic transmission fluid and dust and pollen filter information please refer to the Application Chart.

Oil & Filter Service

An Oil & Filter Service is required every 6 months/8,000 km, whichever occurs first. Every Oil & Filter Service includes the following operations:

- Replace engine oil & filter using 5W30 oil
- Remove & inspect air filter elements
- Lubricate locks, latches & hinges
- Confirm lights, horn & wipers function properly
- Check coolant, brake & washer fluid levels
- Check tires and adjust pressure as required

Maintenance Service

A Maintenance Service is required at 24 months/32,000 km, then every 12 months/16,000 km, whichever occurs first. Every Maintenance Service includes the following operations:

- Replace engine oil & filter using 5W30 oil
- Inspect air filter elements
- Confirm lights, horn & wipers function properly
- Lubricate locks, latches & hinges
- Check coolant, brake & washer fluid levels
- Inspect brake system, tires and rotation
- Inspect exhaust system
- Inspect drive belts for damage, adjust tension if required
- Inspect shocks, ball joints, driveshaft and steering components
- Inspect fuel lines, connectors, fuel tank bands
- Road test

Maintenance Schedule

6 months/8,000 km	Oil & Filter Service
12 months/16,000	Oil & Filter Service

Required Services

- Tire rotation & visual inspection of brakes, steering
- Replace interior dust & pollen filter

18 months/24,000 km Oil & Filter Service

24 months/32,000 km Maintenance & Oil Service

Required Services

- Replace engine coolant
- Replace differential fluid (4WD & RWD)
- Replace transfer case fluid (4WD)
- Replace interior dust & pollen filter
- Lubricate propeller shaft (driveshaft) (4WD Tacoma, 4Runner, Tundra & Sequoia)

30 months/40,000 km Oil & Filter Service

36 months/48,000 km Maintenance & Oil Service

Required Services

- Replace air filter
- Replace spark plugs (standard plugs only)
- Replace auto/manual transmission fluid
- Replace interior dust & pollen filter
- Lubricate propeller shaft
- Grease front wheel bearings (Tacoma RWD)

42 months/56,000 km Oil & Filter Service

48 months/64,000 km Maintenance & Oil Service

Required Services

- Replace engine coolant
- Replace differential fluids (4WD & RWD)
- Replace interior dust & pollen filter
- Lubricate propeller shaft (driveshaft) (4WD Tacoma, 4Runner, Tundra & Sequoia)

54 months/72,000 km Oil & Filter Service

60 months/80,000 km Maintenance & Oil Service

Required Services

- Replace interior dust & pollen filter
- Lubricate propeller shaft (driveshaft) (4WD Tacoma, 4Runner, Tundra & Sequoia)

66 months/88,000 km Oil & Filter Service

72 months/96,000 km Maintenance & Oil Service

Required Services

- Inspect fuel lines & connections, fuel tank vapour vent system hoses, fuel tank bands & fuel tank cap gasket included
- Replace air filter
- Replace spark plugs (all types of plugs)
- Replace timing belt every 72 months/144,000 km
- Replace engine coolant
- Replace auto/manual transmission fluid
- Replace differential fluids (4WD & RWD)
- Replace interior dust & pollen filter
- Lubricate propeller shaft (driveshaft) (4WD Tacoma, 4Runner, Tundra & Sequoia)
- Grease front wheel bearings (Tacoma RWD)

78 months/104,000 km Oil & Filter Service

84 months/112,000 km Maintenance & Oil Service

Required Services

- Replace interior dust & pollen filter
- Lubricate propeller shaft (driveshaft)

90 months / 120,000 km Oil & Filter Service

96 months/128,000 km Maintenance & Oil Service

Required Services

- Replace engine coolant
- Replace differential fluids (4WD & RWD)
- Replace interior dust & pollen filter
- Lubricate propeller shaft (driveshaft)

102 months / 136,000 km Oil & Filter Service

108 months/144,000 km Maintenance & Oil Service

Required Services

- Replace air filter
- Replace spark plugs (standard plugs only)
- Replace timing belt every 72 months/144,000 km
- Replace auto/manual transmission fluid
- Replace differential fluids (4WD & RWD)
- Replace interior dust & pollen filter
- Lubricate propeller shaft (driveshaft)(4WD Tacoma, 4Runner, Tundra & Sequoia)
- Grease front wheel bearings (Tacoma RWD)

78 months / 104,000km Oil & Filter Service

120 months / 160,000 km Maintenance & Oil Service

Required Services

- Inspect fuel lines & connections, fuel tank vapour vent system hoses, fuel tank bands and fuel tank cap gasket included
- Replace engine coolant
- Replace differential fluids (4WD & RWD)
- Replace interior dust & pollen filter
- Lubricate propeller shaft (driveshaft)

126 months / 168,000 km Oil & Filter Service

132 months/176,000 km Maintenance & Oil Service

Required Services

- Replace interior dust & pollen filter
- Lubricate propeller shaft (driveshaft)

APPLICATION CHART

Vehicle	Spark Plugs			A.T.F.		Dust & Pollen Filter
	Standard	Platinum	Iridium	Type T-IV	Other	
Avalon			•		•	•
Camry 00-01		•			•	
Camry 02-03			•	•		•
Celica			•	•		
Corolla 00-02			•			
Corolla 03			•	•		•
Echo 00			•	•		

Echo 01-03		•		•		
Highlander 01			•	•		
Highlander 02-03			•	•		•
Matrix			•	•		•
RAV4 00		•			•	
RAV4 01-03			•	•		•
Sequoia	•				•	
Sienna 00		•			•	
Sienna 01-03			•		•	
Solara 00-01		•			•	
Solara 4 cyl 02-03			•	•		
Solara V6 02-03		•		•		
Tacoma	•				•	
Tundra	•				•	
4Runner 00-02	•				•	
4Runner V6 03	•			•		
4Runner V8 03			•	•		

Please Note:

- Menu excludes Prius and Land Cruiser
 - Waste disposal charges may apply
- Recommended maintenance subject to change